

Ez-MD+ Instructions

Firmware update

Before updating...

- Make sure you are using USB 2.0 port and USB 2.0 cable.
- Be aware that many USB 2.0 are for power charging only. You should use a cable with data transfer capability.

How to update firmware...

1. Connect the ez-MD+ Cross-converter with your PC or laptop using a USB 2.0 cable.
2. Power the ez-MD+ Cross-converter with its AC/DC adaptor.
3. Download "ez-MD+ downloader" and firmware package.
4. Execute "ez-MD+ downloader"
5. Click "File Open" and search for firmware package with recent version.
6. Click Start.
7. Wait until firmware update is finished (can take up to 15 minutes)
8. After finishing unplug the power and re-plug.